



## ***LBE-5AC-Gen2 Quick Start Guide***

### ***Package Contents***



***Antenna Feed***



***Center Reflector Panel***



***Side Reflector Panels (Qty. 2)***



***Feed Receiver***



***Azimuth Mount***



***Elevation Mount***



***Metal Strap***





## LBE-5AC-Gen2 Quick Start Guide

Wingnut Kit

Gigabit PoE\* (24V, 0.3A)  
with Mounting Bracket

Power Cord\*


\* Included only in the single-pack of the LBE-5AC-Gen2.

### Installation Requirements

- 7 mm socket wrench or screwdriver
- Shielded Category 5 (or above) cabling with drain wire should be used for all wired Ethernet connections and should be grounded through the AC ground of the PoE.

We recommend that you protect your networks from harmful outdoor environments and destructive ESD events with industrial-grade, shielded Ethernet cable from Ubiquiti. For more details, visit [ui.com/toughcable](http://ui.com/toughcable)

- Surge protection should be used for all outdoor installations. We recommend that you use two Ethernet Surge Protectors, model ETH-SP, one near the LiteBeam and the other at the entry point to the building. The ETH-SP will absorb power surges and safely discharge them into the ground.






## Application Examples

### LiteBeam AC-Gen2 Quick Start Guide

**The LiteBeam AC mounted outdoors with the reflector installed provides directional outdoor coverage (gain reflector-dependent).**



**The LiteBeam AC mounted outdoors without the reflector installed provides outdoor-to-indoor coverage using the 3 dBi Antenna Feed only.**




## Hardware Overview





## LBE-5AC-Gen2 Quick Start Guide



### 1 Ethernet LED

*The LED will light steady blue when an active Ethernet connection is made and flash when there is activity.*

### 2 Power LED

*The LED will light blue when the device is connected to a power source.*

### 3 Reset Button

*To reset to factory defaults, press and hold the Reset button for more than 10 seconds while the LiteBeam AC is powered on. The LiteBeam AC may also be reset remotely using the auxiliary Reset button located on the bottom of the Gigabit PoE adapter.*

### 4 Ethernet Port


*Supports 10/100/1000 connections and passive PoE. This port should be connected to the LAN and DHCP server.*

## Hardware Installation


1.




# *LBE-5AC-Gen2 Quick Start Guide*



2.




3.



4.




# LBE-5AC-Gen2 Quick Start Guide



5.



# LBE-5AC-Gen2 Quick Start Guide



6.



7.



# LBE-5AC-Gen2 Quick Start Guide



8.



9.





## LBE-5AC-Gen2 Quick Start Guide



### Pole Mounting

1.




2.



# LBE 5AC-Gen2 Quick Start Guide




3.




4.



# LBE-5AC-Gen2 Quick Start Guide




5.





## LBE-5AC-Gen2 Quick Start Guide


6.



7.



## LBE-SAC-Gen2 Quick Start Guide



### Connecting Power



**WARNING:** The switch port must comply with the power specifications listed in this Quick Start Guide.



OR





### Optional



## Accessing airOS via Wi-Fi

Verify connectivity in the airOS® Configuration Interface using the UNMS™ app or Web Portal. Both are available for 15 minutes immediately after you power on the device. If necessary, you can power cycle the device to re-enable its Wi-Fi.

### UNMS App

1. Download the UNMS app.



2. Connect your device's Wi-Fi to the SSID named: <model>:<MAC Address>



**Note:** Ensure that DHCP is enabled on your Wi-Fi adapter.

3. Launch the app and follow the on-screen instructions.

### Web Portal

1. Connect your device's Wi-Fi to the SSID named: <model>:<MAC Address>

**Note:** Ensure that your Wi-Fi connection has DHCP enabled.



## LBE-5AC-Gen2 Quick Start Guide

**2. Launch your web browser and go to: <http://setup.ui.com>**



**3. Select your Country and Language. You must agree to the Terms of Use to use the product. Click Continue.**

Please Set Up Your Device

DEVICE COUNTRY  
Select Country

LANGUAGE  
English

TERMS OF USE  
This Ubiquiti Inc. radio device must be professionally installed. Properly installed shielded Ethernet cable and earth grounding must be used as conditions of product warranty. It is the installer's responsibility to follow local country regulations including operation within legal frequency channels and output power requirements. You are responsible for keeping the unit working according to these rules.  
You must also read and agree to the terms of the [EULA](#) and [PRIVACY POLICY](#) before you can download or install or use the Ubiquiti aROS® Firmware.  
☐ I agree to the Ubiquiti TERMS OF USE, EULA, and PRIVACY POLICY

UPGRADE BACKUP CONFIGURATION

CONTINUE

Have a SmartPhone? Try our new UNMS to install this device

GET IT ON Google Play Download on the App Store

**4. Create a username and password. Confirm your new password and then click Save.**

Create Your Username and Password

CHOOSE YOUR USERNAME  
Username

CHOOSE A STRONG PASSWORD  
Password

CONFIRM NEW PASSWORD  
Confirm Password

BACK SAVE



*The airOS Configuration Interface will appear, allowing you to customize your settings as needed. For additional details, refer to the User Guide available at [ui.com/download/airmax-ac](http://ui.com/download/airmax-ac)*

## Installer Compliance Responsibility

*Devices must be professionally installed and it is the professional installer's responsibility to make sure the device is operated within local country regulatory requirements.*

## Antenna

*Select your antenna from the list. If Calculate EIRP Limit is enabled, transmit output power is automatically adjusted to comply with the regulations of the applicable country. For a Custom antenna, Antenna Gain is entered manually. Note the requirements and antenna types listed below.*

## Cable Loss (When applicable)

*Enter the cable loss in dB. Output power is adjusted to compensate for loss between the radio and the antenna.*





## Certified Antenna Types

### LBE-5AC-Gen2 Quick Start Guide

**This radio transmitter FCC ID: SWX-LBE5ACG2 / IC: 6545A-LBE5ACG2 has been approved by FCC / ISED Canada to operate with the antenna types listed below with the maximum permissible gain for each antenna type indicated. Antenna types not included in this list or having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.**

Antenna	Frequency	Gain
Grid	5 GHz	23 dBi

## Specifications

LBE-5AC-Gen2	
Dimensions	358 x 271.95 x 272.50 mm (14.09 x 10.71 x 10.73")
Weight	
With Mount	980 g (2.16 lb)
Without Mount	800 g (1.76 lb)
Networking Interface	(1) 10/100/1000 Ethernet Port
Antenna Gain	23 dBi
Max. Power Output	25 dBm
Max. Power Consumption	7W
Power Supply	24V, 0.3A Gigabit PoE Adapter*
Power Method	Passive PoE (Pairs 4, 5+; 7, 8 Return)
Operating Temperature	-40 to 70° C (-40 to 158° F)
Operating Humidity	5 to 95% Noncondensing
ESD/EMP Protection	± 24 kV Contact / Air
Shock and Vibration	ETSI300-019-1.4
Wind Survivability	200 km/h (125 mph)
Wind Loading	275 N @ 200 km/h (61.8 lbf @ 125 mph)
Certifications	CE, FCC, IC

**\* Only the single-pack of the LBE-5AC-Gen2 includes a PoE adapter.**



Operation Frequency (MHz)		
Worldwide	5150 - 5875	
US/CA	U-NII-1	5150 - 5250
	U-NII-2A	5250 - 5350
	U-NII-2C	5470 - 5725
	U-NII-3	5725 - 5850
Management Radio (MHz)		
Worldwide	2412 - 2472	
US/CA	2412 - 2462	

## Safety Notices

1. Read, follow, and keep these instructions.
2. Heed all warnings.
3. Only use attachments/accessories specified by the manufacturer.



**WARNING:** Do not use this product in location that can be submerged by water.



**WARNING:** Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.

## Electrical Safety Information

1. Compliance is required with respect to voltage, frequency, and current requirements indicated on the manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment or pose a fire hazard if the limitations are not followed.
2. There are no operator serviceable parts inside this equipment. Service should be provided only by a qualified service technician.
3. This equipment is provided with a detachable power cord which has an integral safety ground wire intended for connection to a grounded safety outlet.
  - a. Do not substitute the power cord with one that is not the provided approved type. Never use an adapter plug to connect to a 2-wire outlet as this will defeat the continuity of the grounding wire.
  - b. The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death.



- LBE-5AC-Gen2 Quick Start Guide**
- c. **Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment.**
  - d. **Protective earthing is provided by Listed AC adapter. Building installation shall provide appropriate short-circuit backup protection.**
  - e. **Protective bonding must be installed in accordance with local national wiring rules and regulations.**

## Limited Warranty

[ui.com/support/warranty](http://ui.com/support/warranty)

**The limited warranty requires the use of arbitration to resolve disputes on an individual basis, and, where applicable, specify arbitration instead of jury trials or class actions.**

## Compliance

### FCC

**Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

**This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.**

- 1. This device may not cause harmful interference, and**
- 2. This device must accept any interference received, including interference that may cause undesired operation.**

**This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operations of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.**

**This radio transmitter has been approved by FCC.**

### ISED Canada

#### CAN ICES-3(A)/NMB-3(A)

**This device complies with ISED Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:**

- 1. This device may not cause interference, and**
- 2. This device must accept any interference, including interference that may cause undesired operation of the device.**



*This radio transmitter has been approved by ISED Canada.*

## **LBE-5AC-Gen2 Quick Start Guide**

*The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.*

### **CAN ICES-3(A)/NMB-3(A)**

*Le présent appareil est conforme aux CNR d'ISDE Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :*

- 1. l'appareil ne doit pas produire de brouillage;*
- 2. l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.*

*Le présent émetteur radio a été approuvé par ISDE Canada.*

*Les dispositifs fonctionnant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.*

### **IMPORTANT NOTE**

#### **Radiation Exposure Statement**

- This equipment complies with radiation exposure limits set forth for an uncontrolled environment.*
- This equipment should be installed and operated with minimum distance 67 cm between the radiator and your body.*
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.*

### **AVIS IMPORTANT**

#### **Déclaration sur l'exposition aux rayonnements**

- Cet équipement est conforme aux limites prévues pour l'exposition aux rayonnements dans un environnement non contrôlé.*
- Lors de l'installation et de la mise en fonctionnement de l'équipement, assurez-vous qu'il y ait une distance minimale de 67 cm entre l'élément rayonnant et vous.*
- Cet émetteur ne doit être installé à proximité d'aucune autre antenne ni d'aucun autre émetteur, et ne doit être utilisé conjointement à aucun autre de ces appareils.*

### **Australia and New Zealand**



**Warning:** *This equipment is compliant with Class A of CISPR 32. In a residential environment this equipment may cause radio interference.*



## Brazil

### LBE-5AC-Gen2 Quick Start Guide



**Nota:** Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados.

## CE Marking

CE marking on this product represents the product is in compliance with all directives that are applicable to it.



### Country List



AT	BE	BG	CY	CZ	DE	DK	EE	EL	ES	FI	FR	HR	HU
IE	IT	LV	LT	LU	MT	NL	PL	PT	RO	SE	SI	SK	UK

**BFWA (Broadband Fixed Wireless Access) members noted in blue**



**Note:** This device meets Max. TX power limit per ETSI regulations.

The following apply to products that operate in the 5 GHz frequency range:



**Note:** This device is restricted to indoor use only when operating in the 5150 - 5350 MHz frequency range within all member states.



**Note:** All countries listed may operate at 30 dBm. BFWA member states may operate at 36 dBm.



**Note:** Operation in the 5.8 GHz frequency band is prohibited in BFWA member states. Other countries listed may use the 5.8 GHz frequency band.

## WEEE Compliance Statement

## Declaration of Conformity



## Online Resources

LBE-5AC-Gen2 Quick Start Guide



© 2020 Ubiquiti Inc. All rights reserved.